



01



02



白磁・絵柄入醤油皿

21-230-01(26230) 富士山 ¥550

φ8.2×H1.8cm

21-230-02(26231) 鯛 ¥550

φ8.2×H1.8cm



03



04




05



06



07



白磁・絵柄入醤油皿

21-230-03(26232) ふくろう ¥550 φ8.2×H1.8cm 21-230-06(26233) ねこ ¥550 φ8.2×H1.8cm

21-230-04(27613) 亀 ¥550 φ8.2×H1.8cm 21-230-07(26299) だるま ¥550 φ8.2×H1.8cm

21-230-05(27614) 鶴 ¥550 φ8.2×H1.8cm



08

白木市松専用トレイ

21-230-08(27001) ¥2,100

14.3×14.3×H2.7cm/内寸12.6×12.6×H2cm

※陶器別売

※陶器は下の「プチ小鉢」よりお選びください



09

10

プチ小鉢

21-230-09(27003) 黒 ¥580 6.3×6.3×H3.5cm

21-230-10(27002) 白 ¥580 6.3×6.3×H3.5cm

※トレイ別売



櫛色料理箱 長角

21-230-11(27182) ¥2,500

26×9.6×H2.7cm/内寸24.4×7.9×H2cm

※陶器別売

※陶器は、下の「強化磁器正角皿(A)」よりお選びください。



強化磁器

12

13

14

15

強化磁器正角皿(A)

21-230-12(26460) 黒 ¥1,000 8×8×H2.3cm

21-230-13(26461) 白 ¥1,000 8×8×H2.3cm

21-230-14(26462) ピンク ¥1,000 8×8×H2.3cm

21-230-15(26463) ブルー ¥1,000 8×8×H2.3cm



16

17

櫛色トレイ

21-230-16(27184) 小 ¥4,100

27.3×10.8×H2cm/内寸21.3×4.7×H1cm

21-230-17(27185) 大 ¥4,800

34.2×10.8×H2cm/内寸28.2×4.8×H1cm

※陶器別売

※陶器は、下の「白磁正角皿(B)」よりお選びください。



18

19

白磁正角皿(B)

21-230-18(26464) 黒 ¥540 7.8×7.8×H2.5cm

21-230-19(26465) 白 ¥540 7.8×7.8×H2.5cm